

## 2001 F-150

\* START OR RUN

Controls idle speed. Duty cycle signals sent by PCM control a solenoid that opens or closes air bypass depending on signal received.

