


ENGINE CONTROLS (5.4L SPORT) 27-4

2001 F-150

* START OR RUN



Regulates vacuum level present in EGR valve to control exhaust gas flow into intake manifold. PCM controls EGR by varying voltage applied to the solenoid.

When PCM grounds valve, fuel vapors which are collected are released to engine for burning.

Provides a voltage related to oxygen content of exhaust gases to PCM for regulating air/fuel ratio.